

SEAT BASE HOLE PATTERN

J700 & J800

Bottom Mounting Pattern

