

ULTRA J SERIES ARMREST

INSTALLATION GUIDE

ULTRA J SERIES ARMRESTS

- Ultra "J" Series



Phone: 1-800-667-7328
Fax: 1-888-667-7328
www.ultraseat.com




ULTRA SEAT CORPORATION

**Product in photo(s) may be different than purchased product,
For additional photos and information please visit
www.ultraseat.com*

15001101

1

Remove the plastic covers on each side of the seat.



2 Armrest Collar Nuts


3

Place the arm bracket over the studs and thread the nuts back onto the studs. Do not over tighten as this may strip the studs.

2

Remove the nuts from the two studs on each side.

ULTRA Series
Ultra J Series Seats



4

Reinstall the plastic covers removed in step 1.

For one seated individual. Maintenance Specialist is recommended. Please visit www.ultraseat.com for more information regarding this product.

ULTRA J SERIES ARMREST INSTALLATION GUIDE